








Machine	Explode	Code	Description
FT691-A Apuro Bain Marie with pans	1		Water Pan
FT691-A Apuro Bain Marie with pans	2		Frame
FT691-A Apuro Bain Marie with pans	3	AL194	Indicator Light
FT691-A Apuro Bain Marie with pans	4	N146	On/Off Switch
FT691-A Apuro Bain Marie with pans	5	AC885	LH Temperature Thermostat
FT691-A Apuro Bain Marie with pans	6	AL195	Chrome Knob
FT691-A Apuro Bain Marie with pans	10		Small Alu Plate
FT691-A Apuro Bain Marie with pans	11	AL197	Auto Recover Thermostat
FT691-A Apuro Bain Marie with pans	12		Pressure Plate for Thermostat Sensor
FT691-A Apuro Bain Marie with pans	13		Main Screw
FT691-A Apuro Bain Marie with pans	14		Bottom Plate
FT691-A Apuro Bain Marie with pans	15	AC883	Rubber Feet
FT691-A Apuro Bain Marie with pans	16		Cover for Heating Element
FT691-A Apuro Bain Marie with pans	17		Pressure Sticker
FT691-A Apuro Bain Marie with pans	18	AL198	Heating Element 1200W
FT691-A Apuro Bain Marie with pans	19		Pressure Plate
FT691-A Apuro Bain Marie with pans	20	AL199	Manual Thermostat
FT691-A Apuro Bain Marie with pans	21		Alu. Plate
FT691-A Apuro Bain Marie with pans	22	AC882	Strain Relief Bushing
FT691-A Apuro Bain Marie with pans	23		Power Cord
FT691-A Apuro Bain Marie with pans	27		GN Pan 1/3x150mm
FT691-A Apuro Bain Marie with pans	28		GN Pan 1/6x150mm
FT691-A Apuro Bain Marie with pans	29		GN Pan Lid 1/3
FT691-A Apuro Bain Marie with pans	30		GN Pan Lid 1/6
FT691-A Apuro Bain Marie with pans	31		Support Bar